

## Printing a Graph

The Graph will be reset when the **START** button is pressed.

At the end of the test, the Graph timer will stop, permitting the Graph to be printed.

During a test or at any time, the Graph Connections (the parameters displayed) may be altered and the scale of each parameter changed. However, it is not possible to change from a Re-Scaling X-Axis to a History Graph without closing the Graph and losing all the history buffer information.

The choice of Re-Scaling X-Axis or a History Graph is made **BEFORE** the Graph is created using the Graph Menu on the **COMPEND** tool bar.

## Graph File Menu

The File Menu permits printing of the Graph at any stage, during the test or at the end of the test when the time axis is frozen.

The Graph may be printed in the format of the window or to fill the page of the printer.

## History Mode Button

If the Graph Setup is **NOT** Autoscale x-axis, then the History Mode Button is active. This permits the graph to be scrolled backwards and forwards through the History Buffer, subject to the maximum capacity of the buffer.

The size of the Graph can be defined in the **Setup Graph** Menu Item of the **Graph** Menu on the **COMPEND** Window tool bar.